



## **STAINLESS WORKS MUFFLER INSTALLATION INSTRUCTIONS**

The muffler in this package has a specific inlet end and outlet end. Looking down the inlet of the muffler, you should see the opening of the louver facing you (in other words, the exhaust airflow stream should flow into the open face of the louver). Looking at the rear of the muffler, the louver should be closed. Installed as directed, these mufflers will deliver great performance and a mellow sound. Stainless Works mufflers are reversible, so if you desire a louder exhaust note you can install them backwards and they will still perform well. For installation, these mufflers can be either welded or clamped in place. If clamping, it is recommended to cut two or four small slots into the end of the muffler stubs to allow the clamps to compress the material and clamp firmly onto the tube. We recommend using a hacksaw or cut off wheel and cutting the slots 3/8" to 5/8" deep -make sure not to cut the slots deeper than the length that the exhaust tube slips into the muffler.

